

# Sound

## Sound:

- 1. Unplug and plug-in again the headphones into the headphone jack.**
- 2. Use the internal speakers and microphone which should work with the volume raised.**
- 3. Connect Bluetooth headphones if available (**  
**<https://support.google.com/chromebook/answer/2587653?hl=en>****).**
- 4. Connect a USB headset if available.**

---

Revision #3

Created 21 January 2022 16:04:26 by Anthony Sinatra

Updated 9 December 2022 17:42:04 by Anthony Sinatra